



INDEX-

PLOT NO	CENTS
1 TO 2	22
3	36
4	30
5	26.5
6	27
7	28
8 TO 11	22
12	34
13 TO 25	22
26	18
27	26.5
28 TO 42	22
43	20
44	28
45 TO 61	22
62	25
63 TO 80	22
81	28
82	26
83 TO 101	22
102	23
103	37
104 TO 123	22
124	21.5
125	26
126 TO 141	22
142	25
143	24.5
144 TO 161	22
162	26
163	39
164 TO 186	22
187	29
188 TO 202	22
203	1
204 TO 214	22
215	32
216	20.1/4
217 TO 226	22
227	35
228	42
229 TO 237	22
238	25
239	25.5
240 TO 242	22
243	28
244 TO 247	22
248	31
249 TO 250	22
251	35
252 TO 265	22
266	50
267	37
268	22
269	21.5
270	33
271 TO 288	22
289	32
290 TO 300	22
301	25
302	27
303 TO 312	22
313	42
314	23.5
315 TO 318	22
319	18.5
320	23
321 TO 324	22
325	21
326 TO 327	22
328	35